

A

Accessories	53
Aiming the Headlamps	71
Air Conditioning	61
Inspection and Testing	62
Operating Controls	63
Over All Performance Test	67
Testing Electrical Switches and Control Circuits	67
Testing Thermal Switch	67
Automatic Beam Changer	75
Driver Adjustments	75
Driving Beam Changer	75
Operation	75
Automatic Choke	43

B

Belt Tension Specifications	42
Brake Adjustment	9
Data and Specifications	10
Master Cylinder	9
Pedal Free Play	9
Torque Specifications	10

C

Camber	7
Carburetor	43
Carter	43
Carter Model AFB (Four Barrel)	43
Caster	7
Checking Timing Chain	31
Circuit Breaker	72
Clutch	10
Pedal Adjustment	10
Pressure Springs	10
Torque Specifications	11
Coil	36
Condenser	36
Connecting Rods and Bearings	31
Constant Level Torsion-Aire	20
Air Springs and Pistons	22
Compressor	25
Compressor Reconditioning	25
Discharging System	22
General Information	20
High Pressure Air Tank	24
Low Pressure Volume Tank	24
Maintenance	28
Operation	20
Rubber Linkage	24
Suspension Height	21
Testing for Leaks	21
Cooling System	41
Data and Specifications	41

D

Distributor	36
Data and Specifications	36
Mechanical Advance and Vacuum Control Specifications	37
Timing	36

E

Electronic Rear View Mirror	76
Description	76
Operation	76
Engine—Data and Specifications	32-33-34
Engine Oiling System—Data and Specifications	35

F

Fan Belt	42
Frame	15
Data and Specifications	15
Front Suspension	7
Data and Specifications	7
General Information	7
Caster and Camber Chart	8
Fuel Data and Specifications	44-45

G

Generator Data and Specifications	39
Generator Regulator Data and Specifications	40

H

Hand Brake	10
Headlamp and Panel Lamp Switches	70
Heater—Hot Water	54
Operation	54
Switch	55
Vacuum Actuators	55
Heater—Gas	55
Breaker Points	57
Burner Assembly	57-58
Burner Blower	55
Heat Exchanger and Overheat Switch	58
Operation	55
Thermostat	59

I

Ignition Timing	36
-----------------------	----

L

Lubrication Chart	78
-------------------------	----

M

Manual Transmission	16
General Information	16

O

Oil Cooler	41
------------------	----

P

Paint Color Code.....	51
Piston Pins—Fitting Piston Pins.....	31
Power Brake	9
PowerFlite Transmission	16
Kickdown Band and Reverse Band Adjustment.....	17
Linkage and Band Adjustments	16
Throttle Linkage and Pressure Adjustment.....	16
Power Steering	15
Gear Lash Adjustment.....	15
Piston	15

Q

Quarter Window	49
----------------------	----

R

Radio	53
Radio Chassis—Removal	53
Rear Axle	8
Data and Specifications	9
Torque Specifications	9

S

Service Brakes	9
Spark Plugs	36
Steering	14
Sure-Grip	8

T

Thermostat	41
Timing Chain and Sprocket Installation.....	31
Toe-In	7
Torque Converter and Housing.....	35
TorqueFlite Transmission	17
Band Adjustment	18
Extension Housing	18
Governor Pressure Chart.....	17
Line Pressure Chart.....	17

U

Universal Joints—Ball and Trunnion.....	12
Cross and Roller.....	12

V

Valve	35
-------------	----

W

Wiring Diagrams	80
-----------------------	----